



32	Lens	Canon EF 85mm f/1.8 USM	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CDAF	CDAF	CDAF	CDAF	CDAF	CDAF	
33		Canon EF 85mm f/1.2L II USM	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CDAF	CDAF	CDAF	CDAF	CDAF	CDAF
34		Canon EF 100mm f/2.0	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CDAF	CDAF	CDAF	CDAF	CDAF	CDAF
35		Canon EF 100mm f/2.8 Macro	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CDAF	CDAF	CDAF	CDAF	CDAF	CDAF
36		Canon EF 135mm f/2.0L	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CDAF	CDAF	CDAF	CDAF	CDAF	CDAF
37		Canon EF 180mm f/3.5 L	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CDAF	CDAF	CDAF	CDAF	CDAF	CDAF
38		Canon EF 200mm f/2.8L	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CDAF	CDAF	CDAF	CDAF	CDAF	CDAF
39		Canon EF 300mm f/4L IS	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CDAF	CDAF	CDAF	CDAF	CDAF	CDAF
40		Canon EF 400mm f/4.0 DO IS USM	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CDAF	CDAF	CDAF	CDAF	CDAF	CDAF
41		Canon EF 400mm f/5.6L	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CDAF	CDAF	CDAF	CDAF	CDAF	CDAF
42		Canon EF 500mm f/4L IS USM	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CDAF	CDAF	CDAF	CDAF	CDAF	CDAF
43		Tamron	Tamron AF 17-50mm f/2.8 Di-II LD	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CDAF	CDAF	CDAF	CDAF	CDAF
44	Tamron 18-270 F3.5-6.3 Di II VC		PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CDAF	CDAF	CDAF	CDAF	CDAF	CDAF
45	Tamron SP24-70mm f/2.8 Di- VC USD		PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CDAF	CDAF	CDAF	CDAF	CDAF	CDAF
46	Tamron 150-600mm f/5-6.3 Di VC USD		PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CDAF	CDAF	CDAF	CDAF	CDAF	CDAF
47	Tamron SP35MM F1.8 DI VC USD		PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CDAF	CDAF	CDAF	CDAF	CDAF	CDAF
48	Sigma	SIGMA 10-20mm f/4-5.6 HSM	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CDAF	CDAF	CDAF	CDAF	CDAF	CDAF
49		SIGMA 24-35mm f/2 DG	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CDAF	CDAF	CDAF	CDAF	CDAF	CDAF
50		SIGMA 24-70mm f/2.8 DG	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CDAF	CDAF	CDAF	CDAF	CDAF	CDAF
51		SIGMA 50-150mm f/2.8 APO DC HSM	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CDAF	CDAF	CDAF	CDAF	CDAF	CDAF
52		SIGMA 70-300mm f/4-5.6 DG	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CDAF	CDAF	CDAF	CDAF	CDAF	CDAF
53		SIGMA 120-300mm f/2.8 DG	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CDAF	CDAF	CDAF	CDAF	CDAF	CDAF
54		SIGMA 24mm f/1.4 DG	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CDAF	CDAF	CDAF	CDAF	CDAF	CDAF
55		SIGMA 35mm f/1.4 DG	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CDAF	CDAF	CDAF	CDAF	CDAF	CDAF
56	SIGMA 85mm f/1.4 DG	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CDAF	CDAF	CDAF	CDAF	CDAF	CDAF	
57	YN	YN EF 50mm f/1.8	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CDAF	CDAF	CDAF	CDAF	CDAF	CDAF