

**SHENZHEN JUEYING TECHNOLOGY CO., LTD.**  
**Compatibility list**

**For: Nikon Lens to Sony Camera Model: NF-E1 Version:V1.2 Tester: Test time:2018-01-02 (update)**

			PDAF					CDAF					Remark
			A9	A7R2	A7M2	A6500	A6300	A7	A7S	NEX-7	A-6000		
1	Nikon Zoom	AF-S 10-24mm f/3.5-4.5G ED	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CD	CD	CD	CD		
2		AF-S 14-24mm f/2.8G N ED	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CD	CD	CD	CD		
3		AF-S 16-35mm f/4.0G ED N VR	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CD	CD	CD	CD		
4		AF-S 16-85MM F3.5-5.6G ED	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CD	CD	CD	CD		
5		AF-S 16-35mm f/1.4G ED N	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CD	CD	CD	CD		
6		AF-S 18-55mm f/3.5-5.6G	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CD	CD	CD	CD		
7		AF-S 18-135mm f/3.5-5.6G ED	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CD	CD	CD	CD		
8		AF-S 18-105mm f/4G ED VR DX	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CD	CD	CD	CD		
9		AF-S 18-200mm f/3.5-5.6G ED VR	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CD	CD	CD	CD		
10		AF-S 18-300MM F3.5-6.3G ED VR DX	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CD	CD	CD	CD		
11		AF-S 24-70mm f/2.8 G ED N	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CD	CD	CD	CD		
12		AF-S 24-120mm f/4 G ED VR N	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CD	CD	CD	CD		
13		AF-S 24-120mm f/3.5-5.6 G ED VR	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CD	CD	CD	CD		
14		AF-S 28-70mm f/2.8 D ED	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CD	CD	CD	CD		
15		AF-S 70-200mm f/2.8GII N ED VR	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CD	CD	CD	CD		
16		AF-S 70-300mm f/4.5-5.6G ED VR	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CD	CD	CD	CD		
17		AF-S 80-200mm f/2.8 D ED	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CD	CD	CD	CD		
18		AF-S 80-400mm f/4.5-5.6G ED VR	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CD	CD	CD	CD		
19	Nikon Prime	AF-S 24mm f/1.4 G ED N	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CD	CD	CD	CD		
20		AF-S 28mm f/1.8G	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CD	CD	CD	CD		
21		AF-S 35mm f/1.8G	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CD	CD	CD	CD		
22		AF-S 40mm f/2.8G DX Micro	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CD	CD	CD	CD		
23		AF-S 50mm f/1.4G	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CD	CD	CD	CD		
24		AF-S 85mm f/1.8G	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CD	CD	CD	CD		
25		AF-S 85mm f/1.4 G N	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CD	CD	CD	CD		
26		AF-S 105mm f/1.4E ED N	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CD	CD	CD	CD		
27		AF-S 105mm f/2.8 G N ED VR MICRO	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CD	CD	CD	CD		
28		AF-S 300mm f/4 D ED	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CD	CD	CD	CD		
29		TAMRON 17-50mm f/2.8	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CD	CD	CD	CD		

30	T A M R O N	TAMRON 18-270mm f/3.5-6.3 24th	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CD	CD	CD	CD			
31		TAMRON 18-270 F3.5-6.3 DiII VC	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CD	CD	CD	CD			
32		TAMRON 18-200mmf/3.5-6.3 [IF]MACRO	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CD	CD	CD	CD			
33		TAMRON SP24-70MM F2.8 DI VC USD G2	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CD	CD	CD	CD			
34		TAMRON 70-300mm f/4-5.6 VC DI	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CD	CD	CD	CD			
35		TAMRON 90mm f/2.8 marco //60	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CD	CD	CD	CD			
36	S I G M A	sigma 8-16mm f/4.5-5.6 HSM	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CD	CD	CD	CD			
37		sigma 10-20mm f/4-5.6 DC HSM	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CD	CD	CD	CD			
38		sigma 18-35mm f/1.8DC	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CD	CD	CD	CD			
39		sigma 24-70mm f/2.8DG HSM EX	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CD	CD	CD	CD			
40		sigma 24-105mm f/4 DG OS	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CD	CD	CD	CD			
41		sigma 50-150mm f/4 DC APO HSM	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CD	CD	CD	CD			
42		sigma 14mm F2.8 D EX	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CD	CD	CD	CD			
43		sigma 20mm F1.4DG	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CD	CD	CD	CD			
44		sigma 50mm F1.4DG HSM	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CD	CD	CD	CD			
45		sigma 85mm f/1.4 dc hsm	PD/CD	PD/CD	PD/CD	PD/CD	PD/CD	CD	CD	CD	CD			